

Incomplete cuts (not cutting through the material)

Troubleshooting cut quality problems	
Too much dross	
Cut angularity	
Incomplete cuts	
Hole quality	

Common causes may include:

1. Worn out/damaged consumables
2. Cutting too fast
3. Incorrect torch height
4. Amperage is too low for the material thickness
5. Incorrect gas/airflow settings

Related content

Gas selection guide for plasma cutting aluminum, stainless steel, and mild steel

[Articles, Tips and techniques, Plasma gas selection](#)

About us

- [Our story](#)
- [News releases](#)
- [Careers](#)
- [Policies](#)

Product lines

- | | |
|----------------------------|--------------------------------|
| XPR
Plasma | HyPerformance
Plasma |
| Powermax
Plasma | LongLife
Plasma |
| DynaMAX
Waterjet | EDGE
CNC |
| ProNest
Software | Robotmaster
Software |

[View all product lines >](#)

Resources

- [Hypertherm Cutting Institute](#)
- [Documents library](#)
- [Xnet access](#)
- [Supplier resource center](#)
- [Product registration](#)

Sign up for our email list

Be the first to learn about new products, educational opportunities, special promotions, and more by subscribing to our email list.

- I have read and agree to the [Privacy Policy](#). [View privacy policy](#)
- Yes, I would like to receive email communications from Hypertherm.

This site is protected by reCAPTCHA and the Google Privacy Policy and Terms of Service apply.